

FWB525M

Before installing and using the product, please read the instruction manual carefully, and properly keep and spare!

Honeycomb Paper automatically Produces the Paper machine



Thank you for choosing the products of the company, the company sincerely provides our distinguished customers with excellent quality products, and will provide professional and reliable after-sales service.

To ensure the personal safety of the users and the safety and integrity of the instruments. Please use it in strict accordance with this instruction manual.

>>> Special explanation

This instruction shall not be used as a basis for any request to the Company.

The company has the right to interpret this instruction manual.

>>> Product use

[Honeycomb paper automatic issuing machine] It is suitable for honeycomb wrapping paper. Because the honeycomb wrapping paper has a pre-cut hole, the wrapping machine will stretch the honeycomb paper wrapping paper Three-dimensional structure, can effectively support and package items, play a good buffer role. The honeycomb paper issuing machine can also place the Sydney paper at the same time. When the machine is running, take the honeycomb paper and Sydney paper together to simplify the packaging steps and make the product packaging in one step and easy to use.

>>> Product characteristics

- 1, Double drum differential operation, high stability
- 2, High power and high capacity motor, longer service life
- 3, Belt drive system, light noise, small vibration
- 4, High temperature resistant silica gel, corrosion resistance, nontoxic, high temperature resistance
- 5, The independent buffer spring is fixed structure, smooth and no lag

6, Independent research and development of control panel, simple interface, perfect function and convenient operation.


7, Structural design is more reasonable, small in appearance, and portable in use

>>> Product Parameter


| Maximum honeycomb paper diameter (mm) | 230mm | | |
|--|--|--|--|
| Maximum honeycomb paper length (mm) | 510mm | | |
| Power Supply Voltage (V / Hz) | 110~220V/50~6OHz | | |
| Consumed power (W) | 230w | | |
| Net weight (kg) | 21kg | | |
| Machine gross weight (kg) | 24kg | | |
| Appearance dimensions LWH (mm) | 689×496×315mm | | |
| Outer box dimensions LWH (mm) | 720mm*450mm*200mm | | |
| Top speed (m / min) | 25m/min | | |
| Ambient condition | Temperature Temperratuer5~40 ° C; 850% RH of humidity Humidity | | |

Instructions for product installation and use


1. Install bracket



2. Put the honeycomb wrapping paper and snow pear paper into the bracket rod, and put it into the machine card slot. Then connect the power supply and the foot switch.



3, Start the machine to step on the foot switch once, and then put the paper close to the drum, the drum will automatically inhale the paper, and then step on the foot switch drum will stop sending paper and cut the paper once.



Operating interface description

| Operation indicator light (When the machine is in the starting state, light up) | Power Supply 电源 ——> ● | | | |
|---|-----------------------------|-------------|--|--|
| Display screen (Used to display the output paper speed, maximum speed 100,minimumof000) | | SPEED 速度 | | |
| Speed adjustment knob (To adjust the speed of the output paper, long press 2 Seconds for reset cutting knife) | START | STOP | | |
| Start the button (After pressing, the operation indicatorlightis on and the machine enters starting state) | 启动 → ▶ | 停止 | | |
| Stop the button (After pressing, the operation indicatorlight | | | | |

(After pressing, the operation indicatorlight goes off and the machine enters the stop state)

Our service purpose

Quality first

Customer orientation

Pioneering and innovating

Steady development

Abide by credit

People oriented

